ESSENCE

DESIGN + ENGINEERING GROHE GERMANY

99.1249.031/ÄM 243750/09.19

www.grohe.com

Pure Freude an Wasser













Application

for shower

Can be used in conjunction with:

- · Pressurised storage heaters
- Thermally controlled instantaneous heaters
- Hydraulically controlled instantaneous heaters

Operation with unpressurised storage heaters (open water heaters) is not possible.

Specifications:

- Flow pressure min. 50 kPa recommended 100 500 kPa
- · Operating pressure max. 500 kPa Test pressure 1600 kPa

If static pressure is greater than 500 kPa, fit pressure reducer. Avoid major pressure differences between hot and cold water supply.

- Temperature Hot water inlet: Recommended:
- · Thermal disinfection possible
- An approved safety device is prescribed according to EN 1717 for combining with bath fillers and pop-up overflows



Installation

Flush piping system prior and after installation of fitting thoroughly (Consider EN 806)!

This product must be installed in conformance with local codes e.g. AS/NZS 3500 series of standard!

Installation, see Fig. [1] - [5]. Refer to the dimensional drawing.

Open cold and hot-water supply and check connections for watertightness!



Check fitting for correct operation.

Maintenance



Inspect and clean all parts, replace as necessary and grease with special grease.

Shut off cold and hot water supply!

Replacing the cartridge.

Assemble in reverse order.

Observe the correct installation position!

Make sure that the cartridge seals engage in the grooves on the housing. Screw in and tighten screwing.



(maximum) 70 °C

(energy saving) 60 °C

Replacement parts

Care

For directions on the care of this fitting, refer to the accompanying Care Instructions.

(AUS)

Reece Australia Pty Ltd 118 Burwood Hwy Burwood VIC 3125

Tel.: +61 3 9274 0000 Email: admin@reece.com.au



(NZ)

Robertson 25 Vestey Drive Mt Wellington, Auckland

Tel.: +64 9 5730490 Email: sales@robertson.co.nz